



## SAFELY REMOVING USB FROM A TCU800

- 1 Ensure that the TCU800 is on and has booted up to its normal operating screen.


- 2 Tap the hamburger menu  in the top left of the screen.  
  
If you do not see the  icon, tap anywhere on the screen once and it will appear.



- 3 Tap **Advanced**.



- 4 Tap **Device Manager**.



- 5 If the USB is in the top slot, Tap **Remove USB 1**.

If the USB is in the bottom slot, Tap **Remove USB 2**.


If both buttons are disabled (greyed out), then skip to step 7.



- 
- 6 Wait for the unmounting process to complete.

If a message displays indicating “Success!...” then tap **Ok** and continue to step 7.

Otherwise, try repeat steps 5 and 6 one more time. If the process fails again, power down the TCU800 and replace the USB drive.



- 
- 7 **Remove** the USB device from the TCU800.